

Norton
REGD. TRADE MARK

**SPARE
PARTS
LIST**

PRICE - 1/-

**NORTON MOTORS LTD.
BRACEBRIDGE STREET
BIRMINGHAM 6 ENGLAND**

GRAMS
"NORTOMO
BIRMINGHAM."

PHONE
ASTON CROSS
0776-7-8.
PRIVATE BRANCH
EXCHANGE

CONTENTS.

	Page No.
Instructions for ordering Spare Parts	2
Crankcases, Flywheels, Main Bearings, etc.	3
Crankcase Bolts	4
Timing Gear and Tappet Parts, etc.	4, 5
Push Rods and Fittings	5
Magneto and Magdyno Driving Parts	5
Lucas Magdyno Parts	6
Dry Sump Oil Pump and Drive Parts	6
Cylinders, Valves, etc.	6, 7
Connecting Rod and Piston Assembly	7
AMAL Carburettors	7, 8
Float Chamber	8
Exhaust Pipes and Silencers	8
Norton Forks and Steering Damper	9
Handlebars and Fittings	10, 11
Petrol and Oil Tanks	11
Gear Box Parts	12, 13
Clutch Group	13
Positive Stop Foot Change Parts	14
Wheel and Hub Parts	14, 15
Transmission	15, 16
Rear Brake Parts	16
Footrest Parts	16
Frames, Mudguards, Stands, etc.	17, 18
Tools	18
Miscellaneous Parts	19
Legshields	19

INSTRUCTIONS FOR ORDERING SPARE PARTS.

This Spare Parts List deals with replacement parts for Models 1, 16H, 18, of 1946.

It is most essential that the Engine and Frame Number of the machine is stated. The Engine Number is to be found on the transmission side of the Crankcase, and the Frame Number is stamped on the Head Lug of the Frame, below the steering damper anchor plate. It is always advisable to order parts on a separate sheet, and not to include on the same sheet other matter of a different nature; this facilities prompt despatch.

It is found in a number of instances that money orders and postal orders are sent in parcels containing patterns; this is inadvisable. We strongly recommend parts as patterns being despatched separately, and a covering letter sent containing the remittance for replacement parts.

RETURNING MACHINES FOR OVERHAULING.

When returning machines or parts for repair or overhaul, these should be sent carriage paid, and with the sender's name and address in full securely attached. It is also advisable to state on the tally that a letter has been sent respecting the parts, and giving the date. All easily detached fittings should be removed, such as Lamps, Horns, Tool Bags, Speedometers, etc.; these are liable to be lost or damaged in transit, and the Company cannot accept any responsibility for them.

ESTIMATES FOR REPAIRING MACHINES.

We are always prepared to give approximate estimates for the cost of repairs; it is quite impossible to give a firm quotation. Additional parts may be found necessary during the process of repair, unforeseen when preparing an estimate. Should our estimate for repair not be accepted, a charge may be made in accordance with work entailed in dismantling and re-assembling. When we give an estimate for the cost of repairs, and this is curtailed by the owner, we cannot accept any responsibility for the performance of the machine; it is always preferable to accept our estimate in full.

TERMS OF BUSINESS.

Our terms are strictly nett cash with order or cash against prepayment invoice. The exact amount, plus 5% to cover postage or carriage and packing (subject to a minimum of 6d.), packing cases or crates to be extra, must be remitted, or when the cost of the parts required is unknown, a sum likely to cover the cost should be enclosed; if the amount remitted is more than the cost of the parts that are ordered, the balance will be returned. Cheques and postal orders should be made payable to "Norton Motors, Ltd.," and crossed Barclays Bank, Ltd. Prices quoted in this list do not include the cost of carriage or fitting. We reserve the right to alter prices or specification of any parts at any time without notice. Where parts are urgently required, remittance may be sent by Telegraphic Money Order, but it is absolutely essential that the sender fill in his name and address in the space provided on the Post Office Money Order Form. Unless this is done, the Post Office do not give us the information in the telegram. It is necessary that all orders given by wire or 'phone should be confirmed by letter at the earliest opportunity.

DEPOSIT ACCOUNT.

We strongly recommend riders of our machines to open a deposit account; this can be done by depositing with us not less than £10. This will ensure goods to that value being despatched with the least possible delay. When ordering by 'phone, wire or post, this often avoids great inconvenience, and for the benefit of the depositor, a monthly statement of account is rendered, showing credit balance. Under no circumstances whatever can parts be despatched without remittance covering same has been sent, unless a deposit account is opened. Should the machine be disposed of at a later date, we are always prepared to remit any amount that may be remaining.

PARTS BY C.O.D. SYSTEM.

Unless remittance is received with order, parts are despatched by C.O.D. System or against pro-forma invoice at our discretion.

CRANKCASES, FLYWHEELS, MAIN BEARINGS, ETC.

New Part No.		For Models	£ s. d.
A2/1	Crankcase with Timing Cover, Magneto Chain Cover, Bushes, Studs, Bolts and Nuts complete	1 & 16H	
A3/1	Crankcase with Timing Cover, Magneto Chain Cover, Bushes, Studs, Bolts and Nuts complete	18	
A2/2	Crankcase Cylinder Stud	1 & 16H	
A3/2	Crankcase Cylinder Stud	18	
A2/3	Crankcase Cylinder Stud Nut	1 & 16H	
A2/4	Crankcase Cylinder Base and Valve Lubrication Stud	1 & 16H	
A2/5	Crankcase Cylinder Base and Valve Lubrication Stud Nut	1 & 16H	
A2/6	Crankcase Timing Cover with Bushes	1, 16H & 18	
NOTE.—When ordering replacement Crankcase Timing Cover it is essential to return the remainder of crankcase for fitting of new cover.			
A2/9	Magneto Chain Cover	1, 16H & 18	
A2/10	Magneto Chain Cover Pipe	1, 16H & 18	
A2/11	Magneto Chain Cover Pipe Union	1, 16H & 18	
A2/12	Timing Cover and Mainshaft Oil Connection jet	1, 16H & 18	
A2/13	Timing Cover and Mainshaft Oil Connection Jet Holder	1, 16H & 18	
A2/14	Timing Cover and Mainshaft Oil Connection Jet Spring	1, 16H & 18	
A2/15	Pressure Release Ball	1, 16H & 18	
A2/16	Pressure Release Ball Spring	1, 16H & 18	
A2/17	Pressure Release Ball Spring Screw	1, 16H & 18	
A2/18	Camshaft Bush (Crankcase) Inlet or Exhaust	1, 16H & 18	
A2/19	Camshaft Bush (Timing Cover) Inlet	1, 16H & 18	
A2/20	Camshaft Bush (Timing Cover) Exhaust	1, 16H & 18	
A2/21	Rocker Shaft Bush (Crankcase)	1, 16H & 18	
A2/22	Rocker Shaft Bush (Timing Cover)	1, 16H & 18	
A2/23	Plug for Inlet Rocker Shaft Bush (Timing Cover)	1, 16H & 18	
A7/24	Flywheels complete with Shafts, Crankpin Bearing, and Connecting Rod	1	
A3/24	Flywheels complete with Shafts, Crankpin Bearing, and Connecting Rod	18	
A2/24	Flywheels complete with Shafts, Crankpin Bearing, and Connecting Rod	16H	
A7/25	Flywheel Timing Side with Shaft only	1	
A2/25	Flywheel Timing Side with Shaft only	16H & 18	
A7/26	Flywheel Driving Side with Shaft only	1	
A2/26	Flywheel Driving Side with Shaft only	16H & 18	
A2/27	Crankpin Bearing with Nuts	1, 16H & 18	
A2/28	Crankpin Bearing Nut	1, 16H & 18	
A2/29	Crankpin Bearing Nut Locking Screw	1, 16H & 18	
NOTE.—Crankpin. Spare Parts cannot be supplied separately, each Outer Race has its individual Pin.			
A2/30	Mainshaft Ball Bearing	1, 16H & 18	
A2/32	Mainshaft Roller Bearing	1, 16H & 18	
A2/33	Mainshaft Bearing Distance Piece	1, 16H & 18	
A2/36	Timing Cover Screw (Cheesehead)	1, 16H & 18	
A2/37	Timing Cover Screw (Countersunk)	1, 16H & 18	
A2/46	Mainshaft Packing Washer	1, 16H & 18	
E.3336	Crankcase Drain Plug	1, 16H & 18	
E.5264	Crankcase Drain Plug Washer	1, 16H & 18	

CRANKCASE, ENGINE PLATE BOLTS, STUDS, ETC.

New Part No.		For Models	£	s.	d.
NOTE.—Length of all Bolts with heads is measured under head.					
E.4256	Mag. Platform Bolt, 7/16" diameter	1, 16H & 18
E.3226	Mag. Platform Nut, 7/16" diameter	1, 16H & 18
E.5377	Mag. Platform Nut Washer	1, 16H & 18
E.3209	Top Crankcase Stud, 5/16" diameter	1, 16H & 18
E.3223	Top Crankcase Stud Nuts, 5/16" diameter	1, 16H & 18
E.5456	Top Crankcase Stud Nut Washer	1, 16H & 18
12747	Front Engine Plate and Horn Bolt, 7/16" diameter	1, 16H & 18
E.3238	Front Engine Plate and Horn Bolt Nut	1, 16H & 18
E.5375	Front Engine Plate and Horn Bolt Nut Washer	1, 16H & 18
E.4256	Rear Engine Plate Bolt, 7/16" diameter	1, 16H & 18
E.3238	Rear Engine Plate Bolt Nut	1, 16H & 18
E.5375	Rear Engine Plate Bolt Washer	1, 16H & 18
E.4268	Rear Engine Plate Bolt, 7/16" diameter	1, 16H & 18
E.5375	Rear Engine Plate Bolt Washer	1, 16H & 18
E.3224	Horn fixing Bolt Nut	1, 16H & 18
11779	Bottom front Crankcase Stud, 3/8" diameter	1, 16H & 18
E.3224	Bottom front Crankcase Stud Nut	1, 16H & 18
E.4259	Rear bottom Crankcase Bolt, 3/8" diameter	1, 16H & 18
E.3224	Rear Crankcase Bolt Nut	1, 16H & 18
E.5376	Rear Crankcase Bolt Washer	1, 16H & 18
E.4262	Engine Cradle Bolt, 5/16" diameter	1, 16H & 18
E.3223	Engine Cradle Bolt Nut	1, 16H & 18
13040	Front Engine Plate Stud, 1/2" diameter	1, 16H & 18
E.3227	Front Engine Plate Stud Nut	1, 16H & 18
11809	Front Engine Plate Stud Nut Washer	1, 16H & 18

TIMING GEARS AND TAPPET PARTS, ETC.

A2/58	Half Time Pinion	1, 16H & 18
A2/59	Half Time Pinion Key	1, 16H & 18
A2/60	Exhaust Cam Wheel complete	1, 16H & 18
A2/61	Inlet Cam Wheel complete	1, 16H & 18
A2/62	Rocker, Inlet or Exhaust (Crankcase)	1 & 16H
A3/62	Rocker, Inlet or Exhaust (Crankcase)	18
A2/63	Tappet Guide Inlet or Exhaust	1 & 16H
A2/64	Exhaust Valve Lifter	1 & 16H
A2/65	Exhaust Valve Lifter Felt Washer	1 & 16H
A2/66	Exhaust Valve Lifter Securing Screw	1, 16H & 18
A2/67	Exhaust Valve Lifter Lever	1, 16H & 18
A2/68	Exhaust Valve Lifter Lever Securing Bolt	1, 16H & 18
A2/69	Exhaust Valve Lifter Return Spring	1 & 16H
A2/70	Valve Cover	1 & 16H
A2/71	Valve Cover Washer	1 & 16H
A2/72	Valve Cover Securing Stud	1 & 16H
A2/73	Valve Cover Securing Knurled Nut	1 & 16H
A2/74	Valve Cover Securing Knurled Nut Fibre Washer	1 & 16H
A7/75	Tappet Adjustable, Inlet	1
A2/75	Tappet Adjustable, Inlet	16H
A7/76	Tappet Adjustable, Exhaust	1
A2/76	Tappet Adjustable, Exhaust	16H
A2/77	Tappet Head	1, 16H
A2/78	Tappet Locknut	1, 16H

TIMING GEARS AND TAPPET PARTS, ETC.—continued.

New Part No.					For Models	£ s. d.
A2/79	Magneto Sprocket (Engine)	1, 16H & 18
A2/80	Magneto Sprocket Locking Nut	1, 16H & 18
A2/81	Magneto Sprocket Key	1, 16H & 18

PUSH RODS AND FITTINGS.

A3/82	Push Rod complete, Inlet and Exhaust	18
A3/83	Push Rod Bottom	18
A3/84	Push Rod Cover	18
A3/85	Push Rod Cover Crankcase Union Nut	18
A3/86	Push Rod Top	18
A3/87	Push Rod Adjuster and Locknut	18
A3/88	Push Rod Cover Bottom Sealing Washer	18
A3/89	Push Rod Cover Top Oil Retaining Washer	18
A3/90	Rocker Box with Covers	18
A3/91	Rocker Box Cover only	18
A3/92	Rocker Box Inspection Cover only	18
A3/93	Rocker Box Cover Screw	18
A3/94	Rocker Box Inspection Cover Screw	18
A3/95	Rocker Box Inspection Cover Washer	18
A3/96	Rocker Box Bush	18
A3/97	Rocker Shaft	18
A3/98	Rocker Shaft Packing Washer	18
A3/99	Rocker Arm or Valve Rocker Arm, Inlet	18
A3/100	Rocker Arm or Valve Rocker Arm, Exhaust	18
A3/101	Rocker Arm Key	18
A3/102	Rocker Arm Nut	18
A3/103	Valve Rocker Arm Nut	18
A3/104	Rocker Arm Ball End	18
A3/105	Valve Rocker Arm Pad	18
A3/106	Rocker Box Distance Pieces (per pair)	18
A3/107	Rocker Box Distance Piece Washer	18
A3/108	Rocker Box Securing Bolt	18
A3/109	Rocker Box Securing Bolt Washer or Stud Nut Washer	18
A3/110	Rocker Box Securing Stud	18
A3/111	Rocker Box Securing Stud Nut	18
A3/64	Exhaust Valve Lifter	18
A3/66	Exhaust Valve Lifter Securing Pin	18
A3/69	Exhaust Valve Lifter Return Spring	18

MAGNETO AND MAGDYNO DRIVING PARTS.

A2/112	Magdyno Sprocket	1, 16H & 18
A2/113	Magdyno Chain	1, 16H & 18
A2/114	Magdyno Chain Spring Link	1, 16H & 18
A2/115	Magdyno Sprocket Securing Nut	1, 16H & 18
A2/116	Magdyno Sprocket Securing Nut Washer	1, 16H & 18
A2/117	Magdyno Platform	1, 16H & 18
E.3831	Magdyno Platform Countersunk Screw	1, 16H & 18
1518A.	Magdyno Platform Countersunk Screw Washer	Shakeproof	1, 16H & 18
A2/118	Magdyno Platform Locking Plate	1, 16H & 18
E.3798	Magdyno Platform Locking Plate Pin	1, 16H & 18

LUCAS MAGDYNO PARTS.

New Part No.					For Models	£ s. d.
A2/119	Contact Breaker complete	1, 16H & 18
A2/120	Contact Points (per set 2)	1, 16H & 18
A2/121	Contact Breaker Centre Screw	1, 16H & 18
A2/122	Contact Breaker Cover	1, 16H & 18
A2/123	H.T. Cable complete with Brush Holder, Brush and Spring	1, 16H & 18
A2/124	H.T. Cable only	1, 16H & 18
A2/125	H.T. Carbon Brush and Spring	1, 16H & 18
A2/126	H.T. Carbon Brush Holder	1, 16H & 18
A2/127	Screwed Bush for Securing H.T Cable to Brush Holder	1, 16H & 18

DRY SUMP OIL PUMP AND DRIVE PARTS.

A2/128	Dry Sump Gear Pump complete	1, 16H & 18
A2/129	Dry Sump Gear Pump Spindle Nut	1, 16H & 18
A2/130	Dry Sump Gear Pump Spindle Worm Gear Wheel	1, 16H & 18
A2/131	Dry Sump Gear Pump Spindle Worm Gear Wheel Key	1, 16H & 18
A2/132	Dry Sump Gear Pump Body and Timing Cover Connection Bush	1, 16H & 18
A2/133	Dry Sump Gear Pump Body and Timing Cover Connection Fibre Washer	1, 16H & 18
A2/134	Engine Mainshaft Pump Driving Worm	1, 16H & 18

NOTE.—Dry Sump Pump parts cannot be supplied separately. It is necessary to return the complete Pump to the Works for attention.

CYLINDERS, VALVES, ETC.

A7/135	Cylinder Barrel with Valve Guides	1
A2/135	Cylinder Barrel with Valve Guides	16H
A3/135	Cylinder Barrel	18
A7/136	Cylinder Head	1
A2/136	Cylinder Head	16H
A7/137	Cylinder Head Joint Washer	1
A2/137	Cylinder Head Joint Washer	16H
A3/137	Cylinder Head Joint Washer	18
A3/136	Cylinder Head with Valve Guides	18
A2/138	Valve Guide Inlet	1 & 16H
A2/139	Valve Guide Exhaust	1 & 16H
A3/140	Valve Guides (Inlet and Exhaust)	18
A2/141	Valve Only (Inlet or Exhaust)	1 & 16H
A3/142	Valve Only (Inlet or Exhaust)	18
A2/144	Valve Spring (Inlet or Exhaust)	1 & 16H
A3/145	Valve Spring Small Inner (Inlet and Exhaust)	18
A3/146	Valve Spring Outer (Inlet and Exhaust)	18
A2/147	Valve Spring Cup Top	1 & 16H
A2/148	Valve Spring Cup Bottom	1 & 16H
A3/147	Valve Spring Cup Top	18
A3/148	Valve Spring Bottom Collar	18
A2/149	Valve Split Cotter (per Valve)	1, 16H & 18
A2/152	Compression Plug	1 & 16H
A2/153	Compression Plug Copper Asbestos Washer	1 & 16H
A2/154	Carburettor Adaptor	1 & 16H

CYLINDERS, VALVES, ETC.—continued.

New Part No.						For Models	£ s. d.
A3/154	Carburetter Adaptor	18
A2/155	Cylinder Head Holding Down Stud	1 & 16H
A3/156	Cylinder Head Holding Down Stud Nut	18
A2/156	Cylinder Head Holding Down Stud Nut	1 & 16H
A3/157	Cylinder Base Paper Washer	18
A2/157	Cylinder Base Paper Washer	1 & 16H

CONNECTING ROD AND PISTON ASSEMBLY.

A2/158	Connecting Rod with Small End Bush	1 & 16H
A3/158	Connecting Rod with Small End Bush	18
A2/159	Small End Bush	1, 16H & 18
A7/160	Piston only	1
A2/160	Piston only	16H
A3/160	Piston only	18
A7/161	Piston ring	1
A2/161	Piston ring	16H & 18
A7/162	Scraper Piston Ring	1
A2/162	Scraper Piston Ring	16H & 18
A2/163	Gudgeon Pin	1, 16H & 18
A2/164	Gudgeon Pin Circlip	1, 16H & 18

AMAL CARBURETTER.

276/AT	Amal-Norton Carburetter complete	1 & 16H
276/AU	Amal-Norton Carburetter complete	18
276/408	Mixing chamber	1 & 16H
276/407	Mixing Chamber	18
6/031	Mixing Chamber Cap	1, 16H & 18
6/032B	Mixing Chamber Top	1, 16H & 18
6/033	Mixing Chamber Union Nut	1, 16H & 18
4/035	Cable Adjusters	1, 16H & 18
4/263	Throttle Valve Spring	1, 16H & 18
6/040	Washer for Jet Block	1, 16H & 18
4/230	Spring Clip for Needle	1, 16H & 18
4/042	Jet No. 160	1, 16H & 18
4/043	Holding Bolt	1, 16H & 18
6/045	Air Valve	1, 16H & 18
4/046	Air Valve Spring	1, 16H & 18
6/047	Air Valve Guide	1, 16H & 18
6/042	Throttle Valve 6/5	1, 16H & 18
6/052	Throttle Valve 6/4	18
4/053	Holding Bolt Washer	1, 16H & 18
206/058	Jet Block and Barrel complete	1 & 16H
206/059	Jet Block and Barrel complete	18
4/060	Split Cotter for Throttle Valve	1, 16H & 18
4/061	Needle Jet	1, 16H & 18
6/065	Needle	1, 16H & 18
13/129	Air Adjusting Screw	1, 16H & 18
16/010	Air Adjusting Screw Locknut	1, 16H & 18
4/235	Spring Clip for Top	1, 16H & 18
4/241	Screw for Spring Clip	1, 16H & 18

AMAL CARBURETTER—continued.

New Part No.	Description	For Models	£	s.	d.
15/2546	Throttle Stop Screw	1, 16H & 18
15/1860	Throttle Stop Body	1, 16H & 18
13/203	Spring	1, 16H & 18
15/1988	Screw	1, 16H & 18
30/109	Air Intake Body	1, 16H & 18
30/080	Air Intake Gauze Spring Clip	1, 16H & 18
6/201	Outlet Clip	1, 16H & 18
4/048	Outlet Clip Pin	1, 16H & 18
30/110	Air Intake Gauze complete	1, 16H & 18

FLOAT CHAMBER.

64/156B	Float Chamber Body	1, 16H & 18
14/208B	Float Chamber Cover	1, 16H & 18
14/014R	Bow Spring for float	1, 16H & 18
14/015	Float	1, 16H & 18
14/021	Cover Locking Screw	1, 16H & 18
14/024	Needle complete	1, 16H & 18
14/209	Tickler	1, 16H & 18
14/210	Tickler Stop	1, 16H & 18
14/032	Tickler Spring	1, 16H & 18
14/289	Tickler Cotter	1, 16H & 18
13/153	Plug Screw	1, 16H & 18
14/039	Plug Screw Washer	1, 16H & 18
14/175	Needle Seating Washer	1, 16H & 18
14/042	Petrol Union Nut	1, 16H & 18
14/041	Petrol Union Nipple	1, 16H & 18
14/035	Banjo	1, 16H & 18
14/036	Banjo Nut	1, 16H & 18
14/037	Banjo Nut Washer	1, 16H & 18
1BE	Float Chamber complete	1, 16H & 18

EXHAUST PIPES AND SILENCERS.

A2/165	Exhaust Pipe only	1 & 16H
A3/165	Exhaust Pipe only	18
A3/166	Exhaust Pipe Flange Washer (Cylinder Head)	18
A3/167	Exhaust Pipe Flange Locking Nut (Cylinder Head)	18
A2/168	Exhaust Pipe Clip	1, 16H & 18
12343	Exhaust Pipe Clip Bolt	1, 16H & 18
E.2339	Exhaust Pipe Clip Bolt Nut	1, 16H & 18
10245	Exhaust Pipe Attachment Bolt	1, 16H & 18
E.3238	Exhaust Pipe Attachment Bolt Nut	1, 16H & 18
E.5375	Exhaust Pipe Attachment Bolt Washer.	1, 16H & 18
A2/169	Silencer	1, 16H & 18
13037	Silencer Support Stud	1, 16H & 18
E.4010	Silencer Sleeve Bolt	1, 16H & 18
E.3224	Silencer Sleeve Bolt Nut	1, 16H & 18
E.5376	Silencer Sleeve Bolt Washer	1, 16H & 18
E.3801	Silencer Clip Bolt	1, 16H & 18
E.3231	Silencer Clip Bolt Nut	1, 16H & 18
11796	Silencer Clip Bolt Nut Washer	1, 16H & 18

NORTON FORKS AND STEERING DAMPER.

New Part No.		For Models	£ s. d.
A2/170	Front Forks complete with Steering Damper and Shock Absorber	1, 16H & 18
A2/171	Front Fork Girder	1, 16H & 18
A2/172	Front Fork Steering Crown and Column	1, 16H & 18
A2/173	Front Fork Steering Crown and Column Ball Race	1, 16H & 18
A2/174	Front Fork Top Clip	1, 16H & 18
A2/175	Handlebar Clip, one only complete	1, 16H & 18
A2/176	Handlebar Clip Pin	1, 16H & 18
A2/177	Front Fork Top Clip Ball Race	1, 16H & 18
A2/178	Front Fork Top Clip Bolt	1, 16H & 18
E.3224	Front Fork Top Clip Bolt Nut	1, 16H & 18
E.5628	Front Fork Top Clip Bolt Bush	1, 16H & 18
A2/179	Front Fork Spring	1, 16H & 18
A2/180	Front Fork Spring Lug	1, 16H & 18
E.5490	Front Fork Spring Attachment Pin	1, 16H & 18
A2/181	Front Fork Top Spindle	1, 16H & 18
A2/182	Front Fork Top or Bottom Spindle nut 1/2"	1, 16H & 18
A2/183	Front Fork Top or Bottom Spindle Nut 7/16"	1, 16H & 18
A2/184	Front Fork Bottom Spindle Rear	1, 16H & 18
A2/185	Front Fork Bottom Spindle Front	1, 16H & 18
A2/186	Front Fork Spindle Knurled Adjusting Washers	1, 16H & 18
A2/187	Front Fork Shock Absorber Friction Disc	1, 16H & 18
A2/188	Front Fork Shock Absorber Adjusting Wheel	1, 16H & 18
A2/189	Front Fork Shock Absorber Adjuster Star Washer	1, 16H & 18
A2/190	Front Fork Bottom Link (right-hand)	1, 16H & 18
A2/191	Front Fork Bottom Link (left-hand)	1, 16H & 18
A2/192	Front Fork Rebound Spring	1, 16H & 18
A2/193	Front Fork Rebound Spring Jaw Joint	1, 16H & 18
A2/194	Front Fork Rebound Spring Jaw Joint Pin	1, 16H & 18
A2/195	Front Fork Rebound Spring Jaw Joint Split Pin	1, 16H & 18
A2/196	Front Fork Top Link (right-hand)	1, 16H & 18
A2/197	Front Fork Top Link (left-hand)	1, 16H & 18
A2/198	Front Fork Grease Nipple	1, 16H & 18
A2/199	Front Fork Mudguard Bracket Plate	1, 16H & 18
A2/200	Front Fork Mudguard Bracket	1, 16H & 18
12343	Front Fork Mudguard Bracket Plate Bolt	1, 16H & 18
E.3222	Front Fork Mudguard Bracket Plate Bolt Nut	1, 16H & 18
A2/201	Front Fork Steering Damper Adjuster	1, 16H & 18
A2/202	Front Fork Steering Damper Adjuster Spring	1, 16H & 18
E.3223	Front Fork Steering Damper Adjuster Spring Nut	1, 16H & 18
A2/203	Front Fork Steering Damper Rod	1, 16H & 18
A2/204	Front Fork Steering Damper Anchor Bracket	1, 16H & 18
A2/205	Front Fork Steering Column Locknut	1, 16H & 18
A2/206	Front Fork Steering Damper Friction Plate	1, 16H & 18
A2/207	Front Fork Steering Damper Friction Disc	1, 16H & 18
A2/208	Front Fork Steering Damper Bottom Plate	1, 16H & 18
E.4276	Front Fork Steering Damper Bottom Plate Fixing Pin	1, 16H & 18
A2/209	Front Fork Steering Damper Bottom Lug	1, 16H & 18
A2/210	Headlamp Brackets each	1, 16H & 18
12342	Headlamp Bracket Pins	1, 16H & 18
E.3222	Headlamp Bracket Pin Nut	1, 16H & 18

HANDLEBAR AND FITTINGS.

New Part No.		For Models	£ s. d.
A2/211	Handlebar Bend only	1, 16H & 18
A2/212	Handlebar End Plug	1, 16H & 18
A2/213	Magneto Control Lever Assembly complete	1, 16H & 18
A2/214	Magneto Control Lever only	1, 16H & 18
A2/215	Magneto Control Lever Body	1, 16H & 18
A2/216	Air Control Lever Assembly complete	1, 16H & 18
A2/217	Air Control Lever only	1, 16H & 18
A2/218	Air Control Lever Body	1, 16H & 18
A2/219	Air or Magneto Control Lever Top Screw	1, 16H & 18
A2/220	Air or Magneto Control Lever Cap	1, 16H & 18
A2/221	Air or Magneto Control Lever Spring Washer	1, 16H & 18
A2/222	Air or Magneto Control Lever Clip	1, 16H & 18
A2/223	Air or Magneto Control Lever Clip Screw	1, 16H & 18
A2/224	Front Brake Lever Assembly complete	1, 16H & 18
A2/225	Front Brake Lever only	1, 16H & 18
A2/226	Clutch Lever Assembly complete	1, 16H & 18
A2/227	Clutch Lever only	1, 16H & 18
A2/228	Front Brake or Clutch Lever Body	1, 16H & 18
A2/222	Front Brake or Clutch Lever Clip	1, 16H & 18
A2/223	Front Brake or Clutch Lever Clip Screw	1, 16H & 18
A2/229	Front Brake or Clutch Lever Pivot Pin	1, 16H & 18
A2/230	Front Brake or Clutch Lever Pivot Pin Nut	1, 16H & 18
A2/231	Front Brake or Clutch Cable Stop	1, 16H & 18
A2/232	Front Brake or Clutch Lever Shakeproof Washer	1, 16H & 18
A2/233	Exhaust Valve Lifter Lever Assembly complete	1, 16H & 18
A2/234	Exhaust Valve Lifter Lever only	1, 16H & 18
A2/235	Exhaust Valve Lifter Lever Body	1, 16H & 18
A2/222	Exhaust Valve Lifter Lever Clip	1, 16H & 18
A2/223	Exhaust Valve Lifter Lever Pivot Pin or Clip Screw	1, 16H & 18
A2/236	Exhaust Valve Lifter Lever Pivot Pin Nut	1, 16H & 18
A2/237	Twist Grip complete	1, 16H & 18
A2/238	Twist Grip Top Half Clip	1, 16H & 18
A2/239	Twist Grip Bottom Half Clip	1, 16H & 18
A2/240	Twist Grip Clip Fixing Pin	1, 16H & 18
A2/241	Twist Grip Control Barrel	1, 16H & 18
A2/242	Twist Grip Control Barrel Adjusting Screw	1, 16H & 18
A2/236	Twist Grip Control Barrel Adjusting Screw Nut	1, 16H & 18
A2/243	Twist Grip Control Barrel Adjusting Screw Spring	1, 16H & 18
A2/244	Twist Grip Cable Stop	1, 16H & 18
A2/245	Twist Grip Canvas or Rubber Cover	1, 16H & 18
A2/246	Dummy Grip to match Twist Grip	1, 16H & 18
A2/247	Front Brake or Clutch Cable Adjuster	1, 16H & 18
A2/248	Exhaust Cable Adjuster	1, 16H & 18
A2/249	Magneto, Air or Throttle Control Cable Nipple, Handlebar End	1, 16H & 18
A2/250	Magneto Control Cable Nipple, Magneto End	1, 16H & 18
A2/251	Air or Throttle Control Cable Nipple Carburetter End	1, 16H & 18
A2/252	Clutch or Front Brake Control Cable Nipple Handlebar End	1, 16H & 18
A2/253	Clutch Control Cable Nipple Gearbox End	1, 16H & 18
A2/254	Front Brake (U Clip End) or Exhaust Lifter Control Cable Nipple (Lifter End)	1, 16H & 18
A2/255	Exhaust Valve Lifter Control Cable Nipple (Handlebar End)	1, 16H & 18
A2/256	Magneto Control Cable Inner and Outer complete	1, 16H & 18

HANDLEBARS AND FITTINGS—continued.

New Part No.		For Models	£ s. d.
A2/257	Magneto Control Cable Outer	1, 16H & 18
A2/258	Magneto Control Cable Inner	1, 16H & 18
A2/259	Air Control Cable Inner and Outer complete	1, 16H & 18
A2/260	Air Control Cable Outer	1, 16H & 18
A2/261	Air Control Cable Inner	1, 16H & 18
A2/262	Throttle Control Cable complete	1, 16H & 18
A2/263	Throttle Control Cable Outer	1, 16H & 18
A2/264	Throttle Control Cable Inner	1, 16H & 18
A2/265	Clutch Control Cable complete	1, 16H & 18
A2/266	Clutch Control Cable Outer	1, 16H & 18
A2/267	Clutch Control Cable Inner	1, 16H & 18
A2/268	Front Brake Control Cable complete	1, 16H & 18
A2/269	Front Brake Control Cable Outer	1, 16H & 18
A2/270	Front Brake Control Cable Inner	1, 16H & 18
A2/271	Exhaust Lifter Control Cable complete	1, 16H & 18
A2/272	Exhaust Lifter Control Cable Outer	1, 16H & 18
A2/273	Exhaust Lifter Control Cable Inner	1, 16H & 18

PETROL AND OIL TANKS.

A2/274	Petrol Tank less all Fittings	1, 16H & 18
A2/275	Petrol Tank Platform Packing Washer (Steel)	1, 16H & 18
A2/276	Petrol Tank Platform Rubber Washer	1, 16H & 18
A2/277	Petrol Tank Attachment Bolt	1, 16H & 18
A2/278	Petrol Tank Attachment Bolt Rubber Washer	1, 16H & 18
A2/279	Petrol Tank Attachment Bolt Rubber Washer Steel Cup	1, 16H & 18
A2/280	Petrol Tank Filler Cap	1, 16H & 18
A2/281	Petrol and Oil Tank Filler Cap Split Cotter	1, 16H & 18
A2/282L	Kneegrip (left-hand)	1, 16H & 18
A2/282R	Kneegrip (right-hand)	1, 16H & 18
E.6629	Kneegrip Pin	1, 16H & 18
A3/283	Petrol Pipe (Rubber)	18
A2/283	Petrol Pipe (Rubber)	1 & 16H
A2/284	Cross-over Petrol Pipe (Copper)	1, 16H & 18
A2/285	Petrol Tap complete with Filter.	1, 16H & 18
E.5264	Petrol Tap Washer	1, 16H & 18
A2/286	Adaptor for Petrol Tap	1, 16H & 18
A2/287	Nut Petrol Tap (Domed)	1, 16H & 18
A2/288	Petrol Pipe Banjo Fibre Washer	1, 16H & 18
A2/289	Petrol Tank Top Tube Packing	1, 16H & 18
A2/290	Oil Tank less all Fittings	1, 16H & 18
A2/291	Oil Tank Filler Cap	1, 16H & 18
A2/292	Oil Tank Union and Filter	1, 16H & 18
A2/293	Oil Tank Union Washer	1, 16H & 18
A2/294	Oil Tank Union Packing Washer	1, 16H & 18
A2/295	Oil Tank Delivery Pipe with Union Nuts and Nipples	1, 16H & 18
A2/296	Oil Tank Return Pipe with Union Nuts and Nipples	1, 16H & 18
12868	Oil Tank Attachment Clip Pin (Mudguard Bridge)	1, 16H & 18
A2/297	Oil Tank Top Attachment Clip (Mudguard Bridge)	1, 16H & 18
E.3223	Oil Tank Attachment Clip Pin Nut	1, 16H & 18
E.3135	Oil Tank Bottom and Battery Carrier Attachment Bolt	1, 16H & 18
12343	Oil Tank Top Attachment Bolt	1, 16H & 18
E.5379	Oil Tank Top Attachment Bolt Washer	1, 16H & 18
A2/298	Oil Tank Air Release Pipe	1, 16H & 18
E.3336	Oil Tank Drain Plug	1, 16H & 18
E.5264	Oil Tank Drain Plug Washer	1, 16H & 18

GEARBOX PARTS.

New Part No.		For Models	£ s. d.
A2/299	Gearbox Shell	1, 16H & 18
A2/300	Gearbox End Cover (Inner)	1, 16H & 18
A2/301	Gearbox End Cover (Outer)	1, 16H & 18
A2/302	Gearbox Clutch Worm Inspection Cover	1, 16H & 18
A2/303	Paper Washer	1, 16H & 18
A2/304	Gearbox Cover Stud (five off)	1, 16H & 18
A2/305	Gearbox Cover Stud (rear middle)	1, 16H & 18
A2/306	Gearbox Cover Stud (bottom)	1, 16H & 18
A2/307	Gearbox Cover Stud Nut	1, 16H & 18
A2/308	Gearbox Cover Stud Spring Washer	1, 16H & 18
A2/309	Gearbox Outer Cover Fixing Screw	1, 16H & 18
A2/310	Gearbox Suspension Bolt and Nut	1, 16H & 18
A2/311	Gearbox Suspension Bolt Nut	1, 16H & 18
A2/312	Gearbox Bottom Bolt and Nut	1, 16H & 18
A2/313	Gearbox Bottom Bolt Nut	1, 16H & 18
A2/314	Gearbox Front Chain Adjuster Plate Assembly	1, 16H & 18
12342	Gearbox Front Chain Adjuster Plate Pin	1, 16H & 18
A2/315	Gearbox Oil Filler Plug	1, 16H & 18
E.3336	Gearbox Oil Drain Plug	1, 16H & 18
A2/316	Main Gear-wheel Bearing complete	1, 16H & 18
A2/317	Main Gear Wheel Oil Retaining Washer	1, 16H & 18
A2/318	Main Gear Wheel Sleeve Bearing Rollers (per set 13)	1, 16H & 18
A2/319	Main Gear Wheel Sleeve Bearing Roller Retaining Washer	1, 16H & 18
A2/320	Main Gear Wheel Bearing Oil Retaining Washer	1, 16H & 18
A2/321	Layshaft R.H. Bearing	1, 16H & 18
A2/322	Layshaft L.H. Bearing	1, 16H & 18
A2/323	Mainshaft Bearing Packing Washer	1, 16H & 18
A2/324	Main Axle	1, 16H & 18
A2/325	Layshaft	1, 16H & 18
A2/326	Main Gear Wheel with Bronze Bush	1, 16H & 18
A2/327	Main Gear Wheel Bush	1, 16H & 18
A2/328	Main Axle Thrust Washer	1, 16H & 18
A2/329	Main Axle Sliding Pinion	1, 16H & 18
A2/330	Main Axle Free Pinion	1, 16H & 18
A2/331	Main Axle Pinion	1, 16H & 18
A2/332	Layshaft Pinion	1, 16H & 18
A2/333	Layshaft Free Pinion	1, 16H & 18
A2/334	Layshaft Sliding Pinion	1, 16H & 18
A2/335	Bush for Main Axle Free Pinion	1, 16H & 18
A2/336	Bush for Layshaft Free Pinion	1, 16H & 18
A2/337	Low Gear and Kick-starter Wheel with Bronze Bush	1, 16H & 18
A2/338	Bronze Bush for Low Gear and Kick-starter Wheel	1, 16H & 18
A2/339	Striker Fork	1, 16H & 18
A2/340	Striker Fork Shaft	1, 16H & 18
A2/341	Cam Plate	1, 16H & 18
A2/342	Cam Plate Spindle	1, 16H & 18
A2/343	Cam Plate Quadrant with Spindle	1, 16H & 18
A2/344	Cam Plate or Quadrant Spindle Bush	1, 16H & 18
A2/345	Quadrant Spindle Oil Retaining Washer (Cork)	1, 16H & 18
A2/346	Cam Plate or Quadrant Spindle Washer	1, 16H & 18
A2/347	Cam Plate or Quadrant Spring Washer	1, 16H & 18
A2/348	Cam Plate or Quadrant Spindle Bolt	1, 16H & 18
A2/349	Cam Plate Quadrant Lever	1, 16H & 18
A2/350	Indexing Plunger	1, 16H & 18

GEARBOX PARTS—continued.

New Part No.						For Models	£ s. d.
A2/351	Indexing Plunger Bush	1, 16H & 18
A2/352	Indexing Plunger Spring	1, 16H & 18
A2/353	Kick-starter Axle with Bronze Bush	1, 16H & 18
A2/354	Bronze Bush for K.S. End of Layshaft	1, 16H & 18
A2/355	Kick-starter Axle Cork Washer	1, 16H & 18
A2/356	Kick-starter Pawl	1, 16H & 18
A2/357	Kick-starter Pawl Pin	1, 16H & 18
A2/358	Kick-starter Return Spring Cover	1, 16H & 18
A2/259	Kick-starter Crank Bolt	1, 16H & 18
A2/360	Kick-starter Crank	1, 16H & 18
A2/361	Kick-starter Cam	1, 16H & 18
A2/362	Kick-starter Rivet	1, 16H & 18
A2/363	Kick-starter Stop Piece	1, 16H & 18
A2/364	Kick-starter Bush	1, 16H & 18
A2/365	Kick-starter Pawl Spring	1, 16H & 18
A2/366	Kick-starter Pawl Spring Plunger	1, 16H & 18
A2/367	Kick-starter Return Spring	1, 16H & 18
A2/308	Spring Washer for Kick-starter Crank Bolt	1, 16H & 18
A2/368	Axle Sprocket	1, 16H & 18
A2/369	Axle Sprocket Locking Nut	1, 16H & 18
A2/370	Axle Sprocket Nut Locking Plate	1, 16H & 18
A2/371	Axle Sprocket Locking Plate Screw	1, 16H & 18
A2/372	Main Axle Nut	1, 16H & 18
A2/373	Axle Nut Lock Washer	1, 16H & 18

CLUTCH GROUP.

A2/374	Clutch Assembly complete	1, 16H & 18
A2/375	Clutch Worm	1, 16H & 18
A2/376	Clutch Worm Nut	1, 16H & 18
A2/377	Clutch Worm Lever	1, 16H & 18
A2/378	Clutch Worm Lever Bolt	1, 16H & 18
A2/379	Clutch Rod	1, 16H & 18
A2/380	Thrust Pin	1, 16H & 18
A2/381	Clutch Back Plate	1, 16H & 18
A2/382	Clutch Roller Cage	1, 16H & 18
A2/383	Clutch Roller (per set)	1, 16H & 18
A2/384	Clutch Sprocket with Inserts	1, 16H & 18
A2/385	Clutch Body	1, 16H & 18
A2/386	Clutch Body Back Cover Plate	1, 16H & 18
A2/387	Clutch Body Centre	1, 16H & 18
A2/388	Clutch Body Centre Rubber Buffers, Large (per set of 3)	1, 16H & 18
A2/389	Clutch Body Centre Rubber Buffers, Small (per set of 3)	1, 16H & 18
A2/390	Clutch Body Front Cover Plate	1, 16H & 18
A2/391	Clutch Body Front Cover Plate Retaining Screw	1, 16H & 18
A2/392	Clutch Plate (Steel)	1, 16H & 18
A2/393	Clutch Friction Plate with Inserts	1, 16H & 18
A2/394	Clutch Friction Plate Inserts (per doz.)	1, 16H & 18
A2/395	Clutch Sprocket Inserts (per doz.)	1, 16H & 18
A2/396	Clutch Plate Cover	1, 16H & 18
A2/397	Clutch Outer Plate	1, 16H & 18
A2/398	Clutch Plate Retaining Ring	1, 16H & 18
A2/399	Clutch Spring	1, 16H & 18
A2/400	Clutch Spring Box	1, 16H & 18
A2/401	Clutch Spring Stud	1, 16H & 18
A2/402	Clutch Spring Stud Nut	1, 16H & 18
A2/403	Clutch Spring Screw	1, 16H & 18

POSITIVE FOOT CHANGE PARTS.

New Part No.		For Models	£ s. d.
A2/404	Gearbox Change Speed Indicator	1, 16H & 18	
A2/405	Change Speed Indicator Bolt	1, 16H & 18	
A2/406	Gear Lever	1, 16H & 18	
A2/407	Gear Lever Rubber	1, 16H & 18	
A2/408	Gear Lever Securing Bolt	1, 16H & 18	
A2/409	Return Spring Cover Plate	1, 16H & 18	
A2/410	Return Spring for Pawl Carrier	1, 16H & 18	
A2/411	Stop Stud for Pawl Carrier	1, 16H & 18	
A2/412	Stop Stud Nut for Pawl Carrier	1, 16H & 18	
A2/413	Peg for Pawl Carrier	1, 16H & 18	
A2/414	Pawl Carrier	1, 16H & 18	
A2/415	Pawl Carrier Spacing Washer	1, 16H & 18	
A2/416	Pawl Carrier Felt Washer	1, 16H & 18	
A2/417	Pawl (plain)	1, 16H & 18	
A2/418	Pawl (forked)	1, 16H & 18	
A2/419	Pawl Return Spring	1, 16H & 18	
A2/420	Pawl Pin	1, 16H & 18	
A2/421	Pawl Pin Nut	1, 16H & 18	
A2/422	Ratchet Plate	1, 16H & 18	
A2/423	Cam Plate	1, 16H & 18	
A2/349	Cam Plate Plunger	1, 16H & 18	
A2/350	Cam Plate Plunger Bush	1, 16H & 18	
A2/351	Cam Plate Plunger Spring	1, 16H & 18	
A2/424	Ratchet Lever	1, 16H & 18	
A2/345	Ratchet Lever Securing Bolt Washer	1, 16H & 18	
A2/346	Ratchet Lever Securing Bolt Spring Washer	1, 16H & 18	
A2/347	Ratchet Lever Securing Bolt	1, 16H & 18	
A2/425	Gearbox Control Rod	1, 16H & 18	
A2/411	Gearbox Control Rod Nut	1, 16H & 18	
A2/426	Gearbox Control Rod Top or Bottom Connection	1, 16H & 18	
A2/427	Gearbox Control Rod Connection Pin	1, 16H & 18	
A2/195	Gearbox Control Rod Connection Split Pin	1, 16H & 18	

WHEEL AND HUB PARTS.

A2/428	Wheel Front or Rear with Hub Shell only	1, 16H & 18	
A2/429	Wheel Spoke Front or Rear (brake-side) 8 1/32" (per set of 20)	1, 16H & 18	
A2/430	Wheel Spoke Front or Rear (plain-side) 8 5/32" (per set of 20)	1, 16H & 18	
A2/431	Wheel Spoke Nipples	1, 16H & 18	
A2/432	Wheel Rim (W.M. 2/19) Front or Rear	1, 16H & 18	
A2/433	Hub Shell only Front or Rear	1, 16H & 18	
A2/434	Hub Shell Bearing Sleeve Front or Rear	1, 16H & 18	
A2/435	Hub Bearing Plain Side	1, 16H & 18	
A2/436	Hub Bearing, Brake Side	1, 16H & 18	
A2/437	Hub Bearing Oil Retaining Felt Washer	1, 16H & 18	
A2/438	Hub Bearing Pen Steel Washer	1, 16H & 18	
A2/439	Hub Bearing Felt Washer Steel Cup Brake Side	1, 16H & 18	
A2/440	Hub Bearing Locking Ring, Plain Side, Front or Rear	1, 16H & 18	

WHEEL AND HUB PARTS—continued.

New Part No.		For Models	£ s. d.
A2/441	Hub Bearing Distance Piece, Plain Side, Front or Rear	1, 16H & 18	
A2/442	Hub Bearing Dust Cover, Plain Side, Front or Rear	1, 16H & 18	
A2/198	Hub Grease Nipple	1, 16H & 18	
A2/443	Hub Brake Shoe with Lining (each	1, 16H & 18	
A2/444	Hub Brake Shoe Lining (per pair)	1, 16H & 18	
A2/445	Hub Brake Shoe Lining Rivet (per set 14)	1, 16H & 18	
A2/446	Hub Brake Shoe Return Spring	1, 16H & 18	
A2/447	Hub Brake Shoe Circlip	1, 16H & 18	
A2/448	Hub Brake Cam with Nut and Washer	1, 16H & 18	
E.3224	Hub Brake Cam Nut	1, 16H & 18	
E.5455	Hub Brake Cam Nut Washer	1, 16H & 18	
A2/449	Hub Brake Cam Bush	1, 16H & 18	
A2/450	Hub Brake Cam Bush Locknut	1, 16H & 18	
A2/451	Wheel Sleeve Nut	1, 16H & 18	
A2/452	Front Hub Spindle	1, 16H & 18	
A2/453	Front Hub Spindle Distance Piece	1, 16H & 18	
A2/454	Front Hub Spindle Nut	1, 16H & 18	
A2/455	Front Hub Brake Plate Distance Nut (Inner)	1, 16H & 18	
A2/456	Front Hub Brake Plate Locking Nut (Outer)	1, 16H & 18	
A2/457	Front Hub Brake Plate	1, 16H & 18	
A2/458	Front Hub Brake Drum	1, 16H & 18	
A2/459	Front Hub Brake Cam Lever	1, 16H & 18	
A2/460	Rear Hub Spindle	1, 16H & 18	
A2/461	Rear Hub Spindle Distance Piece (Plain Side)	1, 16H & 18	
A2/462	Rear Hub Brake Plate	1, 16H & 18	
A2/463	Rear Hub Brake Drum and Sprocket with Studs	1, 16H & 18	
A2/464	Rear Hub Brake Drum and Sprocket Fork End Attachment Piece	1, 16H & 18	
A2/465	Rear Hub Brake Plate Distance Piece (Outer)	1, 16H & 18	
A2/454	Rear Hub Brake Drum and Sprocket Fork End Attachment Piece Nut	1, 16H & 18	
A2/466	Rear Hub Brake Torque Arm	1, 16H & 18	
A2/467	Rear Hub Brake Torque Arm Spring Washer	1, 16H & 18	
E.3812	Rear Hub Brake Torque Arm Frame Bolt	1, 16H & 18	
A2/468	Rear Hub Brake Torque Arm Stud	1, 16H & 18	
11664	Rear Hub Brake Torque Arm Stud Nut	1, 16H & 18	
E.5375	Rear Hub Brake Torque Arm Stud Washer	1, 16H & 18	
A2/469	Rear Hub Brake Cam Lever	1, 16H & 18	
A2/470	Rear Hub Brake Cam Lever Return Spring	1, 16H & 18	
A2/471	Front Brake Drum Stud	1, 16H & 18	
A2/472	Rear Brake Drum Stud	1, 16H & 18	

TRANSMISSION PARTS.

A2/473	Engine Sprocket (State No. of Teeth)	1, 16H & 18	
A2/474	Engine Mainshaft Key	1, 16H & 18	
A2/475	Engine Sprocket Locknut	1, 16H & 18	
A2/476	Crankcase Breather with Pipe	1, 16H & 18	
A2/477	Front Driving Chain, 75 Link	1, 16H & 18	
A3/478	Rear Driving Chain, 91 Link	18	
A2/478	Rear Driving Chain, 90 Link	1 & 16H	
A2/479	Front Chain Spring Link	1, 16H & 18	
A2/480	Front Chain Cranked Link	1, 16H & 18	
A2/481	Rear Chain Spring Link	1, 16H & 18	

TRANSMISSION PARTS—continued.

New Part No.					For Models	£ s. d.
A2/482	Rear Chain Cranked Link	1, 16H & 18
A2/483	Rear Chain Adjuster Bolt and Nut	1, 16H & 18
A2/484	Front Chaincase, Inner Portion	1, 16H & 18
A2/485	Front Chaincase, Outer Portion	1, 16H & 18
A2/486	Front Chaincase Sealing Washer	1, 16H & 18
E.3336	Front Chaincase Drain Plug	1, 16H & 18
E.5264	Front Chaincase Drain Plug Washer	1, 16H & 18
A2/487	Front Chaincase Inspection Disc	1, 16H & 18
A2/488	Front Chaincase Inspection Disc Washer	1, 16H & 18
A2/489	Front Chaincase Inspection Disc Spring Clip	1, 16H & 18
E.6354	Front Chaincase Inner Portion Crankcase Attachment Pin	1, 16H & 18
A2/490	Front Chaincase Pin Locking Plate	1, 16H & 18
E.3223	Front Chaincase Inner Portion Attachment Nut	1, 16H & 18
A2/491	Front Chaincase Inner Portion Attachment Bolt	1, 16H & 18
A2/275	Front Chaincase Inner Portion Attachment Bolt Washer	1, 16H & 18
A2/492	Front Chaincase Inner Portion Crankcase Washer	1, 16H & 18
A2/493	Front Chaincase Inner Portion Gearbox Felt Washer	1, 16H & 18
A2/494	Front Chaincase Inner Portion Footrest Tube Felt Washer	1, 16H & 18
A2/495	Front Chaincase Outer Portion Securing Nut	1, 16H & 18
A2/496	Front Chaincase Outer Portion Securing Nut Washer	1, 16H & 18
A2/497	Rear Chainguard	1, 16H & 18
E.6354	Front Chaincase and Rear Chainguard Securing Pin	1, 16H & 18
12342	Rear Chainguard Attachment Pin	1, 16H & 18

REAR BRAKE PARTS.

A2/498	Rear Brake Pedal	1, 16H & 18
A2/499	Rear Brake Pedal Rubber Pad	1, 16H & 18
A2/500	Rear Brake Pedal Grease Nipple	1, 16H & 18
A2/501	Rear Brake Pedal Adjuster and Locknut	1, 16H & 18
A2/502	Rear Brake Pedal Pivot Bolt	1, 16H & 18
E.3223	Rear Brake Pedal Pivot Bolt Nut	1, 16H & 18
E.5456	Rear Brake Pedal Pivot Bolt Washer	1, 16H & 18
A2/503	Rear Brake Rod	1, 16H & 18
A2/504	Rear Brake Pedal Jaw Joint	1, 16H & 18
A2/505	Rear Brake Adjuster	1, 16H & 18
A2/506	Rear Brake Pedal Jaw Joint Pin	1, 16H & 18
A2/195	Rear Brake Pedal Jaw Joint Pin Split Cotter	1, 16H & 18

FOOTREST PARTS.

A2/507	Footrest Rubber	1, 16H & 18
A2/508	Footrest Rubber Securing Bolt and Nut	1, 16H & 18
A2/509	Footrest Pad Holder	1, 16H & 18
A2/510	Footrest Rod	1, 16H & 18
A2/511	Footrest Rod Nut	1, 16H & 18
A2/512	Footrest Serrated Hanger with Pad Holder Spindle	1, 16H & 18
A2/513	Footrest Serrated Hanger only	1, 16H & 18
A2/514	Footrest Serrated Hanger Spindle only	1, 16H & 18
A2/515	Footrest Serrated Hanger Spindle Nut	1, 16H & 18
A2/516	Rear Engine Plate Left-hand with Footrest Tube	1, 16H & 18
A2/517	Rear Engine Plate Right-hand with Footrest Tube	1, 16H & 18

FRAMES, MUDGUARD, STANDS, ETC.

New Part No.		For Models	£ s. d.
A2/518	Frame only with Head Races	1, 16H & 18
A2/519	Frame Head Race, Top	1, 16H & 18
A2/520	Frame Head Race, Bottom	1, 16H & 18
A2/521	Frame Head Balls (per set)	1, 16H & 18
13061	Frame Fork Stop Bolt	1, 16H & 18
A2/522	Front Engine Plate (Left or Right Hand)	1, 16H & 18
A2/523	Front Engine Plate Cover	1, 16H & 18
A2/524	Prop Stand	1, 16H & 18
A2/525	Prop Stand Frame Pivot Bolt	1, 16H & 18
A2/526	Prop Stand Frame Pivot Bolt Nut	1, 16H & 18
A2/527	Prop Stand Return Spring	1, 16H & 18
A2/528	Frame Bush for Prop Stand Pivot Bolt	1, 16H & 18
A2/529	Front Mudguard only with Front No. Plate Studs	1, 16H & 18
A2/530	Front Mudguard Stay, Left or Right Hand	1, 16H & 18
12342	Front Mudguard Stay Mudguard Attachment Pin	1, 16H & 18
E.3229	Front Mudguard Stay Mudguard Attachment Pin Nut	1, 16H & 18
E.6354	Front Mudguard Stay Fork Attachment Pin	1, 16H & 18
E.3262	Front Mudguard Stand Attachment Bolt	1, 16H & 18
E.3223	Front Mudguard Stand Attachment Bolt Plain Nut	1, 16H & 18
E.3218	Front Mudguard Stand Attachment Bolt Domed Nut	1, 16H & 18
E.5456	Front Mudguard Stand Attachment Bolt Washer	1, 16H & 18
A2/531	Front Number Plate	1, 16H & 18
A2/532	Rear Number Plate	1, 16H & 18
12343	Rear Number Plate Bottom Fixing Pin	1, 16H & 18
E.3222	Rear Number Plate Bottom Fixing Pin Nut	1, 16H & 18
E.5379	Rear Number Plate Bottom Fixing Pin Washer	1, 16H & 18
A2/533	Front Number Plate Attachment Pin and Nut	1, 16H & 18
A2/534	Rear Mudguard complete	1, 16H & 18
A2/535	Rear Mudguard Bottom Portion	1, 16H & 18
12342	Rear Mudguard Bottom Portion Fixing Pins (each)	1, 16H & 18
A2/536	Rear Mudguard Stays and Lifting Handle	1, 16H & 18
E.6453	Rear Mudguard Stays and Lifting Handle Stud (Frame Attachment)	1, 16H & 18
E.3223	Rear Mudguard Stays and Lifting Handle Attachment Stud Nut	1, 16H & 18
A2/537	Rear Mudguard Stay, Left or Right Hand	1, 16H & 18
12342	Rear Mudguard Stay Pin, Mudguard Attachment	1, 16H & 18
E.3222	Rear Mudguard Stay Pin Nut	1, 16H & 18
13059	Rear Mudguard Chain Stay Distance Piece (Short)	1, 16H & 18
5718	Rear Mudguard Chain Stay Distance Piece (Long)	1, 16H & 18
E.5105	Rear Mudguard Seat Stay and Rear Number Plate Bottom Fixing Distance Piece	1, 16H & 18
12868	Rear Mudguard Chain Stay Attachment Bolt	1, 16H & 18
E.3223	Rear Mudguard Chain Stay Attachment Bolt Nut	1, 16H & 18
E.5379	Rear Mudguard Stay Attachment Bolt Washer	1, 16H & 18
A2/538	Toolbox	1, 16H & 18
12343	Toolbox Frame Attachment Bolt	1, 16H & 18
E.3229	Toolbox Frame Attachment Bolt Nut	1, 16H & 18
A2/539	Toolbox Knob	1, 16H & 18
12385	Toolbox Knob Circlip	1, 16H & 18
A2/540	Saddle	1, 16H & 18
A2/541	Saddle Spring (each)	1, 16H & 18
E.6453	Saddle Spring Stud	1, 16H & 18
E.3223	Saddle Spring Stud Nut	1, 16H & 18
E.5456	Saddle Spring Stud Washer	1, 16H & 18

FRAMES, MUDGUARDS, STANDS, ETC.—continued.

New Part No						For Models	£ s. d.
12080	Saddle Front Anchor Bolt	1, 16H & 18
E.3223	Saddle Front Anchor Bolt Nut	1, 16H & 18
E.5379	Saddle Front Anchor Bolt Washer	1, 16 H& 18
A2/542	Rear Stand	1, 16H & 18
11765	Rear Stand Attachment Bolt	1, 16H & 18
11664	Rear Stand Attachment Bolt Nut	1, 16H & 18
A2/543	Rear Stand Spring	1, 16H & 18
A2/544	Front Stand	1, 16H & 18
E.3798	Front Stand Attachment Pin	1, 16H & 18

SPEEDOMETER AND DRIVE PARTS.

A2/545	Speedometer Head Only	1, 16H & 18
A2/546	Speedometer Gearbox only	1, 16H & 18
A2/547	Speedometer Gearbox Locknut	1, 16H & 18
A2/548	Speedometer Gearbox Locknut Spring Washer	1, 16H & 18
A2/549	Gear Ring for Internal Hub Drive	1, 16H & 18
A2/550	Pinion for Internal Front Wheel Drive	1, 16H & 18
A2/551	Pinion Securing Peg	1, 16H & 18
A2/552	Speedometer Cable complete	1, 16H & 18
A2/553	Speedometer Cable Outer	1, 16H & 18
A2/554	Speedometer Cable Inner	1, 16H & 18
A2/555	Speedometer Fork Attachment Bracket	1, 16H & 18
A2/556	Speedometer Head Securing Nut	1, 16H & 18
A2/557	Speedometer Head Securing Nut Spring Washer	1, 16H & 18
A2/558	Speedometer Gearbox Attachment Boss	1, 16H & 18
A2/559	Rivet for Speedometer Gearbox Attachment Boss (per set)	1, 16H & 18
A2/499	Speedometer Attachment Grease Nipple	1, 16H & 18
A2/560	Grease Nipple Adaptor	1, 16H & 18

TOOLS.

A2/561	Tyre Inflator with Connection	1, 16H & 18
A2/562	Tyre Inflator Connection	1, 16H & 18
A2/563	Tool-roll complete with Tools	1 & 16H
A3/563	Tool-roll complete with Tools	18
A2/564	6" Adjustable Spanner	1, 16H & 18
A2/565	Double Ended Spanner 3/16" and 1/4"	1, 16H & 18
A2/566	Double Ended Spanner 5/16" and 3/8"	1, 16H & 18
A2/567	Screw Driver	1, 16H & 18
A2/568	Tappet or Push Rod Adjusting Spanners (per pair)	1, 16H & 18
A2/569	Chain Rivet Extractor	1, 16H & 18
A2/570	Wheel Nut Box Spanner	1, 16H & 18
A3/571	Sparking Plug Spanner	18
A2/572	6" Pliers	1, 16H & 18
A2/573	Tyre Lever	1, 16H & 18
A2/574	Wheel Spindle Spanner	1, 16H & 18
A2/275	Grease Gun	1, 16H & 18
A2/576	Gearbox Top Nut Spanner	1, 16H & 18
A2/577	Sparking Plug Spanner	1 & 16H
A2/578	Single Ended Spanner 1/8"	1, 16H & 18
A3/579	Exhaust Pipe "C" Spanner	18
A2/580	Cylinder Head Nut Spanner	1 & 16H
A2/581	Tommy Bar	1, 16H & 18

MISCELLANEOUS PARTS.

		For Models	£ s. d.
A2/582	Pillion Footrest Hanger L.H. or R.H.	1, 16H & 18	
A2/583	Pillion Footrest Rubber, L.H. or R.H.	1, 16H & 18	
E.3801	Pillion Footrest Attachment Bolt	1, 16H & 18	
5790A	Pillion Footrest Attachment Bolt Spring Washer	1, 16H & 18	
E.3223	Pillion Footrest Attachment Bolt Nut	1, 16H & 18	
A2/584	Pillion Footrest complete with Pins (per pair)	1, 16H & 18	
A2/585	Pillion Seat	1, 16H & 18	
12342	Pillion Seat Attachment Pin	1, 16H & 18	
E.3222	Pillion Seat Attachment Pin Nut	1, 16H & 18	
A2/586	Battery Carrier	1, 16H & 18	
E.6453	Battery Carrier Top Stud	1, 16H & 18	
E.3223	Battery Carrier Top Stud Nut	1, 16H & 18	
E.5456	Battery Carrier Stud Washer	1, 16H & 18	
A2/587	Tail Lamp Attachment Pin and Nut	1, 16H & 18	
A2/588	Voltage Regulator Attachment Clip	1, 16H & 18	
12344	Voltage Regulator Attachment Pin	1, 16H & 18	
E.3222	Voltage Regulator Attachment Pin Nut	1, 16H & 18	
A2/605	Rear Carrier	1, 16H & 18	
	" A " Size Rubber Cable Clip for Frame Top Tube Horn Lead and Headlamp Harness	1, 16H & 18	
	" B " Size Rubber Cable Clip for Speedometer Cable	1, 16H & 18	
	" C " Size Rubber Cable Clip for Front Brake Cable for Battery Lead and Tail Lamp Lead	1, 16H & 18	
	" D " Size Rubber Cable Clip for Speedometer Light Lead and Tail Lamp Lead	1, 16H & 18	

LEGSHIELDS.

A2/589	Legshields and Fittings complete (per set)	1, 16H & 18	
A2/590	Legshield Blade L.H.	1, 16H & 18	
A2/591	Legshield Blade R.H.	1, 16H & 18	
A2/592	Legshield Blade Bracket, L.H or R.H.	1, 16H & 18	
A2/593	Legshield Blade Bracket Back Plate	1, 16H & 18	
12342	Legshield Blade Bracket Pin	1, 16H & 18	
E.3222	Legshield Blade Bracket Pin Nut	1, 16H & 18	
A2/594	Horn Bracket Extension Plate	1, 16H & 18	
11615	Horn Bracket Extension Plate Bolt	1, 16H & 18	
E.3224	Horn Bracket Extension Plate Bolt Nut	1, 16H & 18	
A2/595	Legshield Tank Attachment Bracket L.H.	1, 16H & 18	
A2/596	Legshield Tank Attachment Bracket R.H.	1, 16H & 18	
A2/597	Petrol Tank Front Rubber	1, 16H & 18	
A2/598	Legshield Top Securing Rod	1, 16H & 18	
A2/599	Legshield Bottom Securing Rod	1, 16H & 18	
E.3226	Legshield Securing Rod Nut	1, 16H & 18	
A2/600	Legshield Blade Bracket Distance Tube 3 $\frac{1}{8}$ "	1, 16H & 18	
A2/601	Tank Bracket Distance Tube 1 $\frac{3}{8}$ "	1, 16H & 18	
A2/602	Legshield Blade Tank Bracket Distance Tube 1 $\frac{7}{16}$ "	1, 16H & 18	
A2/603	Legshield Bottom L.H. Distance Tube 5 $\frac{1}{8}$ "	1, 16H & 18	
A2/604	Legshield Bottom R.H. Distance Tube 6 $\frac{7}{8}$ "	1, 16H & 18	