

MOTOR CYCLE



CARBURETTORS



AMAL LTD.,

HOLFORD WORKS, PERRY BARR, BIRMINGHAM, 20

Telegrams: AMALCARB, 'PHONE, BIRMINGHAM.

Telephone: BIRchfields 4571 (5 lines).

1946-7-8 SETTINGS AND SPARE PARTS LIST

Description of Machines	Carburetter Type No.	Mix. Cham. Body No.	Internal Bore	Jet Block Part No.	Jet Size	Throttle Valve	Needle Position	Needle Jet	Float Chbr. Type No.	Float Chbr. Body Part No.	Special Details with Part Numbers.
A.J.S.											
347 O.H.V., Model 16M ..	76D/IJ	76/014	1"	6/058	150	6/4	3	Std.	IJ (15°)	64/186	Locknut for Pilot Adj. Screw and Throttle Stop Screw 4 206. Throttle Spring 29/047.
498 O.H.V., Model 18 ..	89B/IAK	89/403	1 3/32"	29/068	180	29/4	3	Std.	IAK (3°)	64/302	Locknut for Pilot Adj. Screw & Throttle Stop Screw 4 206. Throttle Spring 4 263.
ARIEL.											
347 O.H.V., Model NG ..	275S/IJ	275/400R	7/8"	205/058R	120	5/4	3	Std.	IJ (15°)	64/186	
347 O.H.V., Model NH ..	276AZ/IJ	276/412R	1"	206/058R	150	6/4	3	·1075	IJ (15°)	64/186	
497 O.H.V., Model VG ..	276BB/IJ	276/413R	1 1/16"	206/059R	170	6/4	3	Std.	IJ (15°)	64/186	
497 O.H.V., Model VH ..	289D/IBM	289/403R	1 1/8"	229/069R	200	29/3	3	Std.	IBM (15°)	64/186B	Mix. Chamber Union Nut 29/078.
500 c.c., Twin, Standard, KG	276DA/IDU	276/004R	1 1/8"	206/057R	140	6/3	3	·107	I.D.U.	64/156B	Mixing Chamber Top Spring, 6/419. Air Valve Assembly with Rod 6 417.
500 c.c. Twin, Red Hunter, KH	276DE/IDU	276/014R	1"	206/058R	150	6/3	3	·107	I.D.U.	64/156B	Mixing Chamber Top Spring, 6/419. Air Valve Assembly with Rod 6 417.
598 S.V., Model VB ..	276BP/IJ	276/112R	1"	206/058R	160	6/4	3	Std.	IJ (15°)	64/186	Air Intake Tube 3/8" long.
B.S.A.											
125 c.c., 2-Stroke ..	261/001D	261/001	5/8"	—	75	5	2	·107	—	—	For Spares refer to List 422R.
249 S.V., Model C10 ..	274K/3A	274/024R	25/32"	204/059R	90	4/4	2	·1055	3A	62/025	No Air Valve.
249 O.H.V., Model C11 ..	274L/IAT	274/400R	25/32"	204/059R	80	4/4	3	Std.	IAT (7°)	64/192	No Air Valve.
348 O.H.V., Model B31 ..	276AW/IBB	276/402R	1"	206/058R	150	6/4	3	Std.	IBB (7° & 3°)	64/282	Mixing Chamber Lock Spring 6/248.
348 O.H.V., Model B32 ..	276AW/IBB	276/402R	1"	206/058R	150	6/4	3	Std.	IBB (7° & 3°)	64/282	Mixing Chamber Lock Spring 6/248.
500 c.c., O.H.V., B33 ..	289G/IAT	289/014R	1 1/8"	229/069R	200	29/4	3	Std.	IAT (7°)	64/192	Midway Adjusters in Cables.
500 c.c., O.H.V., B34 ..	289/GIAT	289/014R	1 1/8"	229/069R	200	29/4	3	Std.	IAT (7°)	64/192	Midway Adjusters in Cables.
496 S.V., Model M20 ..	276C/IB	276/014R	1"	206/058R	170	6/4	3	Std.	IB	64/156B	Mixing Chamber Union Nut 6/033.
495 O.H.V. Twin, Model A7	276CG/IA	276/417R	1 1/8"	206/057R	140	6/3	3	Std.	IA	64/156	
500 O.H.V. Twin, A7 (1947-8)	276CY/IA	276/417R	1 1/8"	206/057R	140	6/3	3	·107	IA	64/156	
591 S.V., Model M21 ..	276BR/IB	276/024R	1 1/16"	206/059R	160	6/4	2	Std.	IB	64/156B	Mixing Chamber Union Nut 6/033.
CORGI.											
98 c.c., 2-Stroke	259/001B	259/001B	·425"	—	55	No. 3	2	Std.	Combined with Mix. Chr.		For Spares refer to Parts List No. 422R.
DOUGLAS.											
350 c.c. O.H.V. Transverse	R.H. Carb. 274AJ/4A	274/407R	3/8"	204/058R	75	4/3	2	·107	4A	62/028	Thr. Valve Spring, 4/290.
Twin	L.H. Carb. 274AK/4A	274/408R	3/8"	204/058R	75	4/3	2	·107	4A	62/028	Thr. Valve Spring, 4/290.
E.M.C.											
350 c.c., Twin Piston Engine	289L/2BH	289/022R	1 5/32"	229/070R	200	29/3	3	Std.	2BH	64/177	
EXCELSIOR.											
98 c.c., Model 47/V1 ..	259/001B	259/001B	·425"	—	55	No. 3	3	Std.	Combined with Mix. Chr.		For Spares refer to Parts List No. 422R.
98 c.c., Model 47/G2 ..	259/001B	259/001B	·425"	—	55	No. 3	3	Std.	Combined with Mix. Chr.		For Spares refer to Parts List No. 422R.
100 c.c., Minor	259/021D	259/021D	·531	—	70	5	2	·107	—	—	For Spares refer to List No. 422R.
V. MARTIN & J.A.P.											
500 c.c., Dirt Track ..	27/013	27/013	1 1/8"	27/069	860	12	—	—	14/603	14/603	For Spares refer to List No. 451.
350 c.c., Dirt Track ..	27/002	27/002	1 1/16"	27/068	700	12	—	—	14/603	14/603	For Spares refer to List No. 451.

1946-7-8 SETTINGS AND SPARE PARTS LIST—continued

Description of Machines	Carburettor Type No.	Mix. Cham. Body No.	Internal Bore	Jet Block Part No.	Jet Size	Throttle Valve	Needle Position	Needle Jet	Float Chbr. Type No.	Float Chbr. Body Part No.	Special Details with Part Numbers.
MATCHLESS.											
347 O.H.V., Model G3/L ..	76D/IJ	76/014	1"	6/058	150	6/4	3	Std. 3	IJ (15°)	64/186	Locknut for Pilot Adj. Screw and Throttle Stop Screw 4/206. Throttle Spring 29/047.
498 O.H.V., Model G80 ..	89B/IAK	89/403	1 3/32"	29/068	180	29/4	3	Std.	IAK (3°)	64/302	Locknut for Pilot Adjusting Screw and Throttle Stop Screw 4/206. Throttle Spring 4/263.
350 c.c., O.H.C., Model 7R	T10TT	175/046	1 1/8"	175/108	440	4	4	·109	302/3	302/015	For Spares refer to List No. 449.
NORTON.											
348 O.H.V., Model 350 Trials	276CP/ID	276/012V	1"	206/058	170	6/4	3	Std.	ID	64/156B	Pilot Adj. Screw Nut 16/010. M/c. Union Nut 6/033. Gauze Intake 30/201. Special Throttle Stop.
348 O.H.C., Model 40 ..	T10TT	175/060	1 3/32"	175/101D	350	No. 6	4	·109	14/064 (15°)	14/310	For Spares refer to Parts List No. 441R.
348 O.H.C., Model 40M ..	T10RN	185/060	1 3/32"	185/107	490	No. 6	5	·109	14/532 (15°)	14/225R	For Spares refer to Parts List No. 417R.
348 O.H.V., Model 50 ..	276CP/ID	276/012V	1"	206/058	170	6/4	3	Std.	ID	64/156B	
348 O.H.V., Model 55 ..	276CP/ID	276/012V	1"	206/058	170	6/4	3	Std.	ID	64/156B	Pilot Adj. Screw Nut 16/010.
490 S.V., Model 16H ..	276AT/IBE	276/408V	1"	206/058	160	6/5	3	Std.	IBE	64/156B	M/c. Union Nut 6/033.
490 O.H.V., Model 18 ..	276AU/IBE	276/407V	1 1/16"	206/059	160	6/4	3	Std.	IBE	64/156B	Gauze Intake 30/201.
490 O.H.V., Model 500 Trials	276AU/IBE	276/407V	1 1/16"	206/059	160	6/4	3	Std.	IBE	64/156B	Special Throttle Stop.
490 O.H.V., Model ES2	276AU/IBE	276/407V	1 1/16"	206/059	160	6/4	3	Std.	IBE	64/156B	
490 O.H.C., Model 30 ..	T10TT	175/043	1 3/32"	175/101D	380	No. 7	2	·109	14/064 (15°)	14/310	For Spares refer to Parts List No. 441R.
490 O.H.C., Model 30M ..	T10RN	185/281	1 3/32"	185/107	520	No. 6	4	·109	14/532 (15°)	14/225R	For Spares refer to Parts List No. 417R.
633 S.V., Model No. 1 ..	276AT/IBE	276/408V	1"	206/058	160	6/5	3	Std.	IBE	64/156B	Pilot Adj. Screw Nut 16/010. M/c. Union Nut 6/033. Gauze Intake 30/201. Special Throttle Stop.
PANTHER.											
248 O.H.V., Model 60 ..	274J/3J	274/027R	3/8"	204/059R	90	4/5	3	Std.	3J (15°)	62/032	
250 c.c., Model 65 ..	274AS/3A	274/027R	3/8"	204/059R	90	4/5	3	Std.	3A	62/025	
348 O.H.V., Model 70 ..	275P/1J	275/158R	3/4"	205/058R	110	5/4	3	Std.	IJ (15°)	64/186	
350 c.c., Model 75 ..	275AN/1A	275/158R	3/8"	205/058R	110	5/4	3	Std.	1A	64/156	
598 O.H.V., Model 100 ..	289C/1A	289/402R	1 1/8"	229/069R	220	29/3	3	Std.	1A	64/156	
ROYAL ENFIELD.											
125 c.c., Model RE ..	223/001C	223/001	1 1/16"	—	90	No. 5	3		Combined with Mix. Chr.		For Spares refer to Parts List No. 422R.
346 O.H.V., Model CO ..	276BL/1A	276/405R	1 1/8"	206/057R	130	6/4	3	Std.	1A	64/156	Mixing Chamber Union Nut 6/033.
346 O.H.V., Model G ..	276AC/1A	276/405R	1 1/8"	206/057R	130	6/4	3	Std.	1A	64/156	Mixing Chamber Union Nut 6/033. Gauze Intake 30/109C.
350 c.c., S.V., Model C	274B/1A	274/022R	3/8"	204/059R	85	4/5	3	Std.	1A	64/156	
350 c.c., O.H.V., Model G2	276CX/1A	276/419	1"	206/058R	150	6/4	3	Std.	1A	64/156	Mixing Chamber Union Nut 6/033.
499 O.H.V., Model J ..	276BM/1A	276/001R	1 1/8"	206/057R	140	6/4	3	Std.	1A	64/156	Mixing Chamber Top 6/403.
500 c.c., O.H.V., Mod. J, 1948	276CB/1A	276/011R	1"	206/058R	150	6/4	3	Std.	1A	64/156	
500 c.c., O.H.V., Model J2	276DB/1A	276/130R	1 1/16"	206/059R	170	6/4	2	Std.	1A	64/156	
500 c.c., Twin ..	276DJ/IAT	276/422R	1 1/8"	206/057R	140	6/4	3	·107	IAT (7°)	64/192	Mixing Chamber Union Nut, 6/033.

1946-7-8 SETTINGS AND SPARE PARTS LIST—continued

Description of Machines	Carburetter Type No.	Mix. Cham. Body No.	Internal Bore	Jet Block Part No.	Jet Size	Throttle Valve	Needle Position	Needle Jet	Float Chbr. Type No.	Float Chbr. Body Part No.	Special Details with Part Numbers.
SCOTT.											
98 c.c., Mark II	265/2	265/002	.475"	—	60	No. 3	3	107	Combined with	Mix. Chr.	Jet Needle 259/070. Needle Jet 259/069 (.107). For Spares refer to List No. 422R.
596 c.c., Squirrel	206/151R	206/151R	1 1/16"	206/059R	170	6/3	3	Std.	14/092	14/111	
SUNBEAM.											
480 O.H.V., Twin	276BO/3A	276/132R	1 1/8"	206/057R	150	6/3	3	.1075	3A	62/025	M/c. Top 6/148. Cable Tube 4/278 with Locknut 4/279. Air Intake 244, 290. Air Valve Assembly 30/318. Cable Tube 4/278, with Locknut 4 279.
480 O.H.V., Twin (Export)	276CQ/3A	276/132R	1 1/8"	206/057R	150	6/3	3	.1075	3A	62/025	
TRIUMPH.											
349 O.H.V., De Luxe, 3T	275AD/IA	275/145R	7/8"	205/058R	120	5/4	3	.1075	IA	64/156	Air Valve Assembly with Control Rod 30/306.
349 O.H.V., Tiger, " 85 "	275AD/IA	275/145R	7/8"	205/058R	120	5/4	3	.1075	IA	64/156	Air Valve Assembly with Control Rod 30/306.
498 O.H.V., Tiger " 100 "	276BN/IAT	276/411R	1"	206/058R	160	6/3	3	.1075	IAT	64/192	Air Valve Assembly with Control Rod 30/304.
498 O.H.V., Speed Twin ..	276AX/IAT	276/410R	1 1/8"	206/057R	140	6/3	3	.1075	IAT	64/192	Air Valve Assembly with Control Rod 30/304.
VELOCETTE.											
248 O.H.V., Model MOV	275AB/IJ	275/406R	7/8"	205/058R	120	5/3	3	Std.	IJ (15°)	64/186	Special Throttle Stop Screw and Fittings. (Screw 15/2546, Body 15/1860, Spring 13/203, Screw Body 15/1988).
349 O.H.V., Model MAC ..	276BT/IJ	276/415R	1 1/8"	206/057R	130	6/3	3	Std.	IJ (15°)	64/186	Special Throttle Stop Screw and Fittings. (Part Nos. as above).
348 O.H.C., Model KSS ..	276BU/IJ	276/414R	1"	206/058R	150	6/3	3	Std.	IJ (15°)	64/186	Special Throttle Stop Screw and Fittings. (Part Nos. as above).
348 O.H.C., Mod. KSS (1947-8)	276CV/IJ	276/418R	1 1/16"	206/059R	160	6/3	3	Std.	IJ (15°)	64/186	Special Throttle Stop Screw and Fittings. (Part Nos. as above).
348 O.H.C., Model KTT	T10TT	175/271RR	1 3/32"	175/272D	400	No. 4	2	.109	14/538	14/217R	Mix. Chbr. Connection 14/218. For Spares refer to List No. 441R.
495 O.H.V., Model MSS ..	276BS/IAT	276/416R	1 1/16"	206/059R	180	6/4	3	Std.	IAT (7°)	64/192	Special Throttle Stop Screw and Fittings. (Part Nos. as above).
VINCENT H.R.D.											
998 O.H.V., " B " Rapide	Front Carb. 276CJ/IDO	276/022R	1 1/16"	206/059R	170	6/4	3	Std.	IDO	64/156B	Mixing Chamber Top 6/403. Cable Ferrules 6/132.
	Rear Carb. 276CH/2DS	276/022R	1 1/16"	206/059R	170	6/4	3	Std.	2DS	64/163	Mixing Chamber Top 6/403. Cable Ferrules 6/132.
998 c.c., O.H.V., Special ..	Front Carb. 289M/IDO	289/011R	1 1/8"	229/069R	200	29/4	3	Std.	IDO	64/156B	
	Rear Carb. 289N/2DS	289/011R	1 1/8"	229/069R	200	29/4	3	Std.	2DS	64/161	

MIXING CHAMBER SPARE PARTS



COMPONENT	274 B	274 J	274 K & L AS	274 AJ AK	Price s. d.	275 AB	275 AD	275 S & P AN	Price s. d.	89 B	289 C L	289 D	289 G	289 MN	Price s. d.
Mixing Chamber Body					10 0		Refer to		12 0	Settings	List for	Part Numbers			16 0
Jet Block complete					7 6		Refer to		7 6	Settings	List for	Part Numbers			10 0
Mixing Chamber Top	4/032	4/032	4/032	4/032	2 6	4/032	—	4/032	2 6	29/042	29/042	29/042	29/300	29/300	3 3
Mixing Chamber Cap Ring	4/031	4/031	4/031	4/031	2 6	4/031	4/031	4/031	2 6	29/401	29/041	29/041	29/041	29/041	3 0
Fixing Spring for Cap	4/235	4/235	4/235	4/235	9	4/235	4/235	4/235	9	29/201	29/201	29/201	29/201	29/201	9
Screw for Fixing Spring for Cap	4/241	4/241	4/241	4/241	2	4/241	4/241	4/241	2	4/241	4/241	4/241	4/241	4/241	2
Cable Adjuster	4/035	4/035	4/035	4/035	6	4/035	4/035	4/035	6	4/035	4/035	4/035	—	—	6
Cable Top Hat Ferrules	—	—	—	—	—	—	—	—	—	—	—	—	6/132	6/132	3
Cable Tube	—	—	—	—	—	—	—	—	—	—	—	—	—	—	—
Cable Tube Locknut	—	—	—	—	—	—	—	—	—	—	—	—	—	—	—
Throttle Valve	4/052	4/052	4/052	4/052	6 0	5/052	5/052	5/052	6 0	29/062	29/062	29/062	29/062	29/062	6 6
Throttle Valve Spring	4/263	4/263	4/263	4/290	4	4/263	—	4/263	4	4/263	29/047	29/047	29/047	29/047	4
Throttle Valve Cotter Pin	4/060	4/060	4/060	4/060	1	4/060	—	4/060	1	4/060	4/060	4/060	4/060	4/060	1
Taper Needle	4/065	4/065	4/065	4/065	2 0	5/065	5/065	5/065	2 0	29/075	29/075	29/075	29/075	29/075	2 0
Needle Clip	4/230	4/230	4/230	4/230	6	4/230	4/230	4/230	6	4/230	4/230	4/230	4/230	4/230	6
Air Valve	4/045	—	4/045	4/045	3 9	5/045	—	5/045	3 9	29/055	29/055	29/055	29/055	29/055	4 0
Air Valve Guide	4/047	—	4/047	4/047	1 0	5/047	—	5/047	1 0	29/057	29/057	29/057	29/057	29/057	1 3
Air Valve Spring	4/046	—	4/046	4/046	4	4/046	—	6/046	4	4/046	4/046	4/046	4/046	4/046	4
Air Valve Assembly complete with M/c. Top and Con. Rod	—	—	—	—	—	—	30/306	—	8 9	—	—	—	—	—	—
Needle Jet	4/061	4/061	4/061	4/061	2 6	4/061	4/061	4/061	2 6	29/076	29/076	29/076	29/076	29/076	2 6
Main Jet	4/042	4/042	4/042	4/042	8	4/042	4/042	4/042	8	4/042	4/042	4/042	4/042	4/042	8
Mixing Chamber Union Nut	4/062	4/062	4/062	4/062	2 3	4/062	4/062	4/062	2 3	29/072	29/072	29/078	29/078	29/072	3 0
Washer for Mixing Chamber Union Nut	4/040	4/040	4/040	4/040	2	4/040	4/040	4/040	2	29/050	29/050	29/050	29/050	29/050	2
Holding Bolt for Float Chamber	4/043	4/043	4/043	4/043	3 0	4/043	4/043	4/043	3 0	29/077	29/077	29/077	29/077	29/077	3 0
Washer for Holding Bolt for Float Chamber	4/053	4/053	4/053	4/053	2	4/053	4/053	4/053	2	4/053	4/053	4/053	4/053	4/053	2
Pilot Air Adjusting Screw	13/129	13/129	13/129	12/129	9	13/129	13/129	13/129	9	13/129	13/129	13/129	13/129	13/129	9
Pilot Air Adjusting Spring	4/148	4/148	4/148	—	3	4/148	4/148	4/148	3	4/206	4/148	4/148	4/148	4/148	3
Pilot Air Adjusting Locknut	—	—	—	16/010	2	—	—	—	—	—	—	—	—	—	—
Throttle Stop Screw	4/063	4/063	4/063	4/063	9	—	4/063	4/063	9	4/063	4/063	4/063	4/063	4/063	9
Throttle Stop Screw Locknut	16/010	16/010	16/010	16/010	2	—	16/010	16/010	2	4/206	16/010	16/010	16/010	16/010	2
Throttle Stop Screw with Tommy Bar	—	—	—	—	—	15/2546	—	—	1 2	—	—	—	—	—	—
Body for Throttle Stop Screw with Tommy Bar	—	—	—	—	—	15/1860	—	—	1 2	—	—	—	—	—	—
Screw for Throttle Stop Screw with Tommy Bar	—	—	—	—	—	15/1988	—	—	1	—	—	—	—	—	—
Spring for Throttle Stop Screw with Tommy Bar	—	—	—	—	—	13/203	—	—	4	—	—	—	—	—	—
Outlet Clip	4/207	—	—	—	2 6	—	—	—	—	—	—	—	—	6/201	2 6
Outlet Clip Screw	4/048	—	—	—	6	—	—	—	—	—	—	—	—	4/048	6
Air Intake Tube	—	4/038	4/038	4/038	3 0	4/038	4/038	4/038	3 0	29/048	29/048	29/048	—	29/048	3 6
Gauze Intake complete	30/330C	—	—	—	6 9	—	—	—	—	—	—	—	—	—	—
Gauze Intake, Body only	30/109	—	—	—	3 5	—	—	—	—	—	—	—	—	—	—
Gauze Intake, Gauze	30/110	—	—	—	1 6	—	—	—	—	—	—	—	—	—	—
Gauze Intake Clip	30/080	—	—	—	1 2	—	—	—	—	—	—	—	—	—	—
Gauze Intake Adaptor	30/129	—	—	—	1 6	—	—	—	—	—	—	—	—	—	—
Strangler Intake, complete	—	—	—	—	—	—	—	—	—	—	—	—	—	—	—
Strangler Intake Cowl	—	—	—	—	—	—	—	—	—	—	—	—	—	—	—
Strangler Intake Cowl Nut	—	—	—	—	—	—	—	—	—	—	—	—	—	—	—
Strangler Intake Fixing Clip	—	—	—	—	—	—	—	—	—	—	—	—	—	—	—
Strangler Intake Fixing Clip Pin	—	—	—	—	—	—	—	—	—	—	—	—	—	—	—
Strangler Intake Fixing Pin Nut	—	—	—	—	—	—	—	—	—	—	—	—	—	—	—

MIXING CHAMBER SPARE PARTS—continued

COMPONENT	76 D	208 276 AZ, BB, BP, CG	276 AC	276 AT, AU, CP	276 AW	276 BL, BR, C	276 BO	276 AX, BN	276 BS, BT, BU, CV	276 BM, CH, CJ, CB	276 CQ	276 CX DJ	276 CY	276 DB	276 DE DA	Price s. d.	
Mixing Chamber Body	Refer	to Settings	List for Part	Numbers			Refer to Settings	List for Part	Numbers							14 0	
Jet Block complete	Refer	to Settings	List for Part	Numbers			Refer to Settings	List for Part	Numbers							7 6	
Mixing Chamber Top	6/032	6/032	6/032	6/032	6/032	6/032	6/148	—	6/032	6/403	—	6/403	6,032	6,403	—	2 6	
Mixing Chamber Cap Ring	6/031	6/031	6/031	6/031	6/031	6/031	6/031	6/031	6/031	6/031	6/031	6/031	6,031	6,031	6,031	2 6	
Fixing Spring for Cap	4/235	4/235	4/235	4/235	4/235	6/248	4/235	4/235	4/235	4/235	4/235	4/235	4/235	6/248	4/235	6/419	9
Screw for Fixing Spring for Cap	4/241	4/241	4/241	4/241	4/241	4/241	4/241	4/241	4/241	4/241	4/241	4/241	4/241	4/241	4/241	2	
Cable Adjuster	4/035	4/035	4/035	4/035	4/035	4/035	4/035	4/035	4/035	—	—	—	4/035	—	4,035	6	
Cable Top Hat Ferrules	—	—	—	—	—	—	—	—	—	6/132	—	6/132	—	6,132	—	3	
Cable Tube	—	—	—	—	—	—	4/278	—	—	—	4/278	—	—	—	—	1 3	
Cable Tube Locknut	—	—	—	—	—	—	4/279	—	—	—	4/279	—	—	—	—	2 0	
Throttle Valve	6/052	6/052	6/052	6/052	6/052	6/052	6/052	6/052	6/052	6/052	6/052	6/052	6,052	6,052	6,052	6 0	
Throttle Valve Spring	4/263	4/263	4/263	4/263	4/263	4/263	4/263	—	4/263	4/263	4/263	4/263	4/263	4/263	4/263	4	
Throttle Valve Cotter Pin	4/060	4/060	4/060	4/060	4/060	4/060	4/060	—	4/060	4/060	4/060	4/060	4/060	4/060	4/060	1	
Taper Needle	6/065	6/065	6/065	6/065	6/065	6/065	6/065	6/065	6/065	6/065	6/065	6/065	6,065	6,065	6,065	2 0	
Needle Clip	4/230	4/230	4/230	4/230	4/230	4/230	4/230	4/230	4/230	4/230	4/230	4/230	4/230	4/230	4,230	6	
Air Valve	6/045	6/045	6/045	6/045	6/045	6/045	6/045	—	6/045	6/045	—	6/045	6/045	6/045	—	3 9	
Air Valve Guide	6/047	6/047	6/047	6/047	6/047	6/047	6/047	—	6/047	6/047	—	6/047	6/047	6/047	—	1 0	
Air Valve Spring	4/046	4/046	4/046	4/046	4/046	4/046	4/046	—	4/046	4/046	—	4/046	4/046	4/046	—	4	
Air Valve Assembly com.M/c. Top & Control Rod	—	—	—	—	—	—	—	30/304	—	—	30/318	—	—	—	6,417	8 9	
Needle Jet	4/061	4/061	4/061	4/061	4/061	4/061	4/061	4/061	4/061	4/061	4/061	4/061	4/061	4/061	4/061	2 6	
Main Jet	4/042	4/042	4/042	4/042	4/042	4/042	4/042	4/042	4/042	4/042	4/042	4/042	4/042	4/042	4/042	8	
Mixing Chamber Union Nut	6/062	6/062	6/033	6/033	6/062	6/033	6/062	6/062	6/062	6/062	6/062	6/033	6/062	6/062	6,062	2 3	
Washer for Mixing Chamber Union Nut	6/040	6/040	6/040	6/040	6/040	6/040	6/040	6/040	6/040	6/040	6/040	6/040	6/040	6/040	6,040	2	
Holding Bolt for Float Chamber	4/043	4/043	4/043	4/043	4/043	4/043	4/043	4/043	4/043	4/043	4/043	4/043	4/043	4/043	4/043	3 0	
Washer for Holding Bolt for Float Chamber	4/053	4/053	4/053	4/053	4/053	4/053	4/053	4/053	4/053	4/053	4/053	4/053	4/053	4/053	4,053	2	
Pilot Air Adjusting Screw	13/129	13/129	13/129	13/129	13/129	13/129	13/129	13/129	13/129	13/129	13/129	13/129	13/129	13/129	13/129	9	
Pilot Air Adjusting Spring	—	4/148	4/148	—	4/148	4/148	4/148	4/148	4/148	4/148	4/148	4/148	4/148	4/148	4,148	3	
Pilot Air Adjusting Locknut	4/206	—	—	16/010	—	—	—	—	—	—	—	—	—	—	—	2	
Throttle Stop Screw	4/063	4/063	4/063	—	4/063	4/063	4/063	4/063	—	4/063	4/063	4/063	4/063	4/063	4,063	9	
Throttle Stop Screw Locknut	16/010	16/010	16/010	—	16/010	16/010	16/010	16/010	—	16/010	16/010	16/010	16/010	16,010	16,010	2	
Throttle Stop Screw with Tommy Bar	—	—	—	15/2546	—	—	—	—	15/2546	—	—	—	—	—	—	1 2	
Body for Throttle Stop Screw with Tommy Bar	—	—	—	15/1860	—	—	—	—	15/1860	—	—	—	—	—	—	1 2	
Screw for Throttle Stop Screw with Tommy Bar	—	—	—	15/1988	—	—	—	—	15/1988	—	—	—	—	—	—	1	
Spring for Throttle Stop Screw with Tommy Bar	—	—	—	13/203	—	—	—	—	13/203	—	—	—	—	—	—	4	
Outlet Clip	—	—	(5/200=AT	6/201=AU, CP)	—	—	—	—	(5/200=BM, CB	6/201=CH, CJ)	—	—	—	—	—	2 6	
Outlet Clip Screw	—	—	—	4/048	—	—	—	—	—	4/048	—	—	—	—	—	6	
Air Intake Tube	6/038	6/038	—	—	6/038	6/038	—	6/038	6/038	6/038	—	6/038	—	6,038	6,038	3 0	
Gauze Intake, complete	—	—	30/109C	30/201	—	—	—	—	—	—	—	—	—	—	—	6 9	
Gauze Intake, Body only	—	—	30/109	30/109	—	—	—	—	—	—	—	—	—	—	—	3 5	
Gauze Intake, Gauze	—	—	30/110	30/110	—	—	—	—	—	—	—	—	—	—	—	1 6	
Gauze Intake Clip	—	—	30/080	30/080	—	—	—	—	—	—	—	—	—	—	—	1 2	
Strangler Intake, complete	—	—	—	—	—	—	244/290	—	—	—	—	—	—	—	—	12 0	
Strangler Intake Cowl	—	—	—	—	—	—	224/034	—	—	—	—	—	—	—	—	3 0	
Strangler Intake Cowl Nut	—	—	—	—	—	—	224/018	—	—	—	—	—	—	—	—	3	
Strangler Intake Fixing Clip	—	—	—	—	—	—	34/017	—	—	—	—	—	—	—	—	9	
Strangler Intake Fixing Clip Pin	—	—	—	—	—	—	15/927	—	—	—	—	—	—	—	—	4	
Strangler Intake Fixing Pin Nut	—	—	—	—	—	—	16/010	—	—	—	—	—	—	—	—	2	
Strangler Intake Adaptor	—	—	—	—	—	—	34/015	—	—	—	—	—	—	—	—	1 6	

FLOAT CHAMBER SPARE PARTS

COMPONENT	1A	1B	1D	1J	1AK	1AT	1BB	1BE	1BM	1DO	2DN	1DU	2BH	2DS	14/092	Price s. d.	3A	3J	4A	Price s. d.
Float Chamber Body only	64/156	64/156B	64/156B	64/186	64/302	64/192	64/282	64/156B	64/186B	64/156B	64/163	64/156B	64/176	64/161	14/092	14 0	62/025	62/032	62 028	10 6
Cover Complete	14/208	14/208	14/208	14/208	14/208	14/208	14/208	14/208	14/208	14/208	14/297	14/208B	14/012	14/297	14/012	3 9	22/011	22/011	22 012	3 9
Cover Lock Screw, Standard	14/021	14/021	14/021	14/021	14/021	14/021	14/021	14/021	14/021	14/021	—	14/021	—	—	—	4	—	—	—	—
Cover Lock Screw, 1/8 in.	—	—	—	—	—	—	—	—	—	—	3319	—	—	3319	—	2	—	—	—	—
Tickler complete	14/301	14/301	14/301	14/301	14/301	14/301	14/301	14/301	14/301	14/301	14/301	14/301	14/301	14/301	14/301	1 4	22/062	22/062	22/062	1 4
Tickler only	14/209	14/209	14/209	14/209	14/209	14/209	14/209	14/209	14/209	14/209	14/209	14/209	14/209	14/209	14/209	10	22/021	22/021	22 021	10
Tickler Spring	14/032	14/032	14/032	14/032	14/032	14/032	14/032	14/032	14/032	14/032	14/032	14/032	14/032	14/032	14/032	2	14/032	14/032	14/032	2
Tickler Cotter Pin	14/289	14/289	14/289	14/289	14/289	14/289	14/289	14/289	14/289	14/289	14/289	14/289	14/289	14/289	14/289	1	14/289	14/289	14/289	1
Tickler Stop	14/210	14/210	14/210	14/210	14/210	14/210	14/210	14/210	14/210	14/210	14/210	14/210	14/210	14/210	14/210	3	22/037	22/037	22/037	3
Float complete	14/015	14/015	14/015	14/015	14/015	14/015	14/015	14/015	14/015	14/015	14/017	14/015	14/017	14/017	14/017	3 9	22/016	22/016	22/016	3 9
Float Bow Spring	14/014	14/014	14/014	14/014	14/014	14/014	14/014	14/014	14/014	14/014	—	14/014	14/014	—	—	4	—	—	—	—
Float Needle Valve	14/024	14/024	14/024	14/024	14/024	14/024	14/024	14/024	14/024	14/024	14/030	14/024	14/030	14/030	14/030	1 6	22/013	22/013	22 014	1 6
Needle Clip	—	—	—	—	—	—	—	—	—	—	161/054	—	161/054	161/054	161/054	2	—	—	—	—
Plug Screw (Body Arm)	13/153	13/153	13/153	13/153	13/153	13/153	13/153	13/153	13/153	13/153	13/153	13/153	13/153	13/153	13/153	3	—	—	—	—
Washer for Plug Screw (Body Arm)	14/039	14/039	14/039	14/039	14/039	14/039	14/039	14/039	14/039	14/039	14/039	14/039	14/039	14/039	14/039	1	—	—	—	—
Seating Locknut	14/178	—	—	14/178	14/178	14/178	14/178	—	—	—	—	14/178	14/178	—	—	4	14/178	14/178	—	4
Seating Washer	14/175	—	—	14/175	14/175	14/175	14/175	—	—	—	—	14/175	14/175	—	—	2	14/175	14/175	—	2
Banjo Connection (Single)	—	14/035	—	—	—	—	—	14/035	14/054	14/054	—	14/049	—	—	—	3 0	—	—	—	—
Banjo Connection (Double)	—	—	14/173	—	—	—	—	—	—	—	14/110	—	—	14/110	—	6 9	—	—	—	—
Banjo Nut	—	14/036	14/036	—	—	—	—	14/036	14/036	14/036	14/036	14/036	—	14/036	—	9	—	—	—	—
Banjo Washer	—	14/037	14/037	—	—	—	—	14/037	14/037	14/037	14/037	14/037	—	14/037	—	2	—	—	—	—
Petrol Union Nut	14/042	14/042	14/042	14/042	14/042	14/042	14/042	14/042	—	—	—	—	14/042	—	14/042	9	14/042	14/042	14/042	9
Petrol Union Nipple	14/026	14/026	14/026	14/026	14/026	14/026	14/026	14/041	—	—	—	—	14/026	—	14/026	5	14/026	14/026	14/026	5
Price of Complete Float Chamber	s. d.	s. d.	s. d.	s. d.	s. d.	s. d.	s. d.	s. d.	s. d.	s. d.	s. d.	s. d.	s. d.	s. d.	s. d.		s. d.	s. d.	s. d.	
	23 0	26 9	29 9	23 0	23 0	23 0	23 0	26 9	26 9	26 9	29 9	26 9	23 0	29 9	23 0		19 6	19 6	19 6	

1,000/149. W.

Printed in England.

ALL PRICES ARE SUBJECT TO ALTERATION WITHOUT NOTICE.

AMAL LIMITED,

HOLFORD WORKS, PERRY BARR, BIRMINGHAM, 20.

Telegrams: "Amalcarb," 'Phone, Birmingham.

Telephone: BIRchfields 4571 (5 lines).